


HOME DECORATORS C O L L E C T I O N

BF-25154 APOTHECARY HUTCH 34"H×42"W×8"D

INV#16075













ASSEMBLY INSTRUCTIONS





















Made In China



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.



IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST		
A  TOP PANEL-1PC	B  LEFT SIDE PANEL-1PC	C  RIGHT SIDE PANEL-1PC
D  UP ADORNING PANEL-1PC	E  STAND PANELS-5PCS	F  ACROSS PANEL-1PC
G  STAND PANEL-2PCS	H  ACROSS PANEL-1PC	I  STAND PANEL-5PCS
J  ACROSS PANEL-1PC	K  STAND PANELS-2PCS	L  ACROSS PANEL-1PC

M  DOWN ADORNING PANEL-1PC	N  UP BACK PANEL-1PC	O  MIDDLE BACK PANEL-1PC	
P  DOWN BACK PANEL-1PC	Q  CAM-T00L-1PC 7mm × 5/8 "	R  CAM-BOLTS-22PCS 6mm × 5/8 "	
S  CAM-LOCKS-22PCS	T  SCREWS-58PCS	U  SCREWS-8PCS	
V  HOOKS-4PCS 7mm × 7/8 "	W  SCREWS-4PCS 6mm × 3/4 "	X  GECKOS-4PCS	Y  PLASTIC BELTS-2PCS
Z  SCREWS-4PCS 8mm × 1-1/4 "	A1  DOWELS-58PCS	B1  PLATES-2PCS	C1  SCREWS-4PCS 8mm × 1 "
D1  SCREWS-14PCS	E1  CAM-LOCK CAPS-4PCS	F1  EVA PADS-4PCS	




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1). ASSEMBLE THE STAND PANEL (G).

- INSERT 4 DOWELS(A1) INTO THE HOLES IN THE ACROSS PANEL (F).
- ATTACH THE STAND PANELS(G) TO ACROSS PANEL (F).




2). ASSEMBLE THE ACROSS PANEL (H).

- INSERT 4 DOWELS(A1) INTO THE HOLES IN THE ACROSS PANEL (H).
- ATTACH THE ACROSS PANEL (H) TO STAND PANELS (G).




3). ASSEMBLE THE STAND PANEL (K).

- INSERT 4 DOWELS(A1) INTO THE HOLES IN THE ACROSS PANEL (J).
- ATTACH THE STAND PANELS(K) TO ACROSS PANEL (J).




4). ASSEMBLE THE ACROSS PANEL (L).

- INSERT 4 DOWELS(A1) INTO THE HOLES IN THE PANEL (L).
- ATTACH THE ACROSS PANEL (L) TO STAND PANELS(K) USING 4 SCREWS (D1).




5). ASSEMBLE THE STAND PANEL(I).

- INSERT 10 DOWELS(A1) INTO THE HOLES IN THE ACROSS PANEL(H).
- ATTACH THE STAND PANELS(I) TO THE ACROSS PANEL(H).




6). ASSEMBLE THE ACROSS PANEL(J).

- INSERT 10 DOWELS(A1) INTO THE HOLES IN THE ACROSS PANEL(J).
- ATTACH THE STAND PANELS(I) TO THE ACROSS PANEL(J).




7). ASSEMBLE THE DOWN ADORNING PANEL(M).

- ROTATE 1 CAM-BOLT(R) AND INSERT 1 DOWEL(A1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE CAM-BOLT(R) INTO THE HOLES IN THE DOWN ADORNING PANEL(M) AND ATTACH USING 1 CAM-LOCK (S).




8). ASSEMBLE THE LEFT SIDE PANEL(B).

- ROTATE 8 CAM-BOLTS(R) INTO THE HOLES IN THE LEFT SIDE PANEL(B).
- PLACE CAM-BOLTS(R) INTO THE HOLES IN THE PANEL (F/H/J/L) AND ATTACH USING 8 CAM-LOCKS (S).




9). ASSEMBLE THE RIGHT SIDE PANEL(C).

- ROTATE 9 CAM-BOLTS(R) AND INSERT 1 DOWEL(A1) INTO THE HOLES IN THE RIGHT SIDE PANEL(C).
- PLACE CAM-BOLTS(R) INTO THE HOLES IN THE PANEL(F/H/J/L/M) AND ATTACH USING 9 CAM-LOCKS(S).




10). ASSEMBLE THE STAND PANEL(E).

- INSERT 10 DOWELS(A1) INTO THE HOLES IN THE ACROSS PANEL(F).
- ATTACH THE STAND PANEL(E) TO THE ACROSS PANEL(F).




11). ASSEMBLE THE TOP PANEL (A).

- ROTATE 4 CAM-BOLTS (R) INTO THE HOLES IN THE TOP PANEL (A).
- INSERT 10 DOWELS (A1) INTO THE HOLES IN THE PANELS (E).
- PLACE CAM-BOLTS (R) INTO THE HOLES IN THE PANEL (B/C) AND ATTACH USING 4 CAM-LOCKS (S).
- ROTATE 10 SCREWS (D1) INTO THE HOLES IN THE TOP PANEL (A).



12). ASSEMBLE THE UP ADORNING PANEL (D).

- ATTACH THE UP ADORNING PANEL (D) TO TOP PANEL (A) USING 3 SCREWS (C1).




13). ASSEMBLE THE CAM-LOCK CAPS(E1).

- ATTACH THE 4 CAM-LOCK CAPS(E1) ONTO THE 4 CAM-LOCKS(S).


Warning

The anti-tip hardware must be used as part of assembly!




14). ASSEMBLE THE BACK PANEL (N/O/P).

- ATTACH THE BACK PANEL (N/O/P) USING 58 SCREWS (T).
- ATTACH 2 HOOKS (V) USING 4 SCREWS (W) IN THE PREDRILLED HOLES OF REAR TOP PANEL (A).





15). ASSEMBLE THE EVA PADS(F1).

- ATTACH 4 EVA PADS(F1) TO SIDE PANEL (B/C).



16). ASSEMBLE THE PLATES(B1).

- ATTACH THE PLATES(B1) TO THE SIDE PANEL (B/C) USING 8 SCREWS(U).



17). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO WALL, PLEASE REFER TO THE REAR TOP PANEL'S HOLES DISTANCE AND HEIGHT.
- PUT 4 GECKOS(X) INTO HOLES IN THE WALL, AND ROTATE 4 SCREWS(Z) INTO THE GECKOS(X).
- CONNECT THE TWO HOOKS(V) WITH A PLASTIC BELT(Y).